

ScratchMaster[®] Care & Maintenance

Maintenance

Your Next Floor[®] Luxury Vinyl floor is durable and easy to clean. Effective maintenance of your flooring is common sense, all good maintenance procedures consist of thorough dirt and grit control, removal of spills and the protection of the floor surface.

Walk off mats can help considerably reduce the amount of grit brought in by foot traffic, sweeping, mopping and vacuuming all help to control grit. Damp mopping, spot cleaning and washing will remove most spills and stains. The local conditions of your area will determine specific maintenance needs. Prepare an appropriate maintenance program that meets the needs of the specific facility.

Regular Maintenance

- Sweep or vacuum the floor to remove all loose dirt and grit.
- Damp mop the floor with a cleaning solution or detergent recommended for use on vinyl flooring - always read the product label to ascertain suitability and follow the manufacturer's instructions for application.
- Rinse and allow to dry.
- Buff the floor with a dry soft mop or cloth.

Caution

- Steam mops may damage your ScratchMaster[®] flooring and should not be used.
- Cigarettes and other hot objects of high temperature can scar the surface of the floor.
- Certain types of rubber should be avoided unless it is known they are non-staining.
(e.g. rubber backed mats – always confirm compatibility with mat supplier before using any mat)
- Asphalt type products are known to cause PVC to yellow. Care must be taken to avoid stains from these types of products
(e.g. residue brought in from newly laid drives, roads etc.)

Care for Immediately After Installation

- Remove all loose dirt by sweeping or vacuuming with suitable domestic vacuum cleaner (ensure the smooth flooring setting is selected).
- When returning heavy furniture and appliances to the room always use strips of plywood or hardboard to protect the floor. Install wide-bearing, non-staining felt protectors on all movable furniture.
- Remove all loose dirt by sweeping or vacuuming with suitable domestic vacuum cleaner (ensure the smooth flooring setting is selected).
- Remove any residual adhesive from the surface following the adhesive manufacturer's instructions.
- Foot traffic and cleaning is acceptable immediately after installation for Click / Floating Floors.

Preventive Care / Routine Maintenance

- Sweep or vacuum (without beater brush) at least once weekly or more often to remove loose dirt, sand and grit from your floor.
- Check felt protectors on movable furniture periodically for grit and wear and replace when necessary.
- Heavy appliances and furniture that are not moved often should have square 1 1/2" to 2 5/8" or round from 1 3/8" to 1 5/8" flat, non-staining composition furniture sliders installed.
- Place mats at outside entrances to prevent dirt, grit, water, snow, or ice from being tracked onto your floor.

Warning Next Floor[®] luxury flooring can be quite slippery when wet. All necessary precautions should be taken when maintaining flooring of this type. Allow for adequate dry time after washing and wipe up all wet areas immediately. Improper cleaners or polishes may also cause slipperiness.